



SHELBY TRAILER SERVICE, LLC

P.O. Box 148

Comanche, OK 73529

(580) 252-2922

(580) 252-2821 Fax

Cross lug board installation instructions:

- The boards can run the length of the trailer or the width of the trailer depending on preference.
- Bracing must run perpendicular to the board.
- The brace center to center distance shall not exceed 12 inches (2 x 2 x 3/16 angle is recommended for bracing).
- Each board must be secured to the frame at least every 24 inches (trailer floor screws are preferred).
- Allow ¼ inch space for boards less than 10 feet in length and ½ inch space for boards above 10 feet to 24 feet in length between the end of the board and trailer frame for thermal expansion.
- The board can be ripped with a carbide tip saw blade. It is recommended that a spray lubricant be put on the blade before and intermittently during the cut.